

STORM

AQUANAUT

SETTING THE TIME & DATE

Unscrew anti-clockwise and pull out the top crown to set date/time. Pull crown to the first click position for date and second click for time adjustment. After setting date/time, please screw the crown back tight to ensure water resistance. Do not operate crowns when the watch is wet or in water.

INTERNAL ROTATING BEZEL

The Internal rotating bezel can show up to 60 minutes of elapsed time. To rotate bezel turn bottom crown and align triangle marker with the minute hand. You can then read the elapsed time (from that point) on the rotating bezel.

NB This is not a professional divers watch.



05/10